



Printer Color Profile Instructions

Color profiles are data files that contain a description of how a particular paper, ink, and printer create all colors, shades, and densities. Using a profile will result in more accurate and consistent output.

Printer: Epson Stylus Pro 3880

Driver / Printer Properties Setting Recommendations

Mode: Off No Color Adjustment

Print Quality: Quality Options / Level 4 (1440x720) – High Speed optional

Support

How to install profiles

www.redriverpaper.com/installprofiles

How to use profiles

www.redriverpaper.com/useprofiles

Some Hints



The name of the paper you are using will not be listed in the media setting drop down menu in the printer driver. That menu only has the names of manufacturer papers.

Do not use the printer driver's "Preview before printing feature". It can interrupt the color management process.

Turn on your printer's thick paper setting when using heavy weight papers.

Epson Printers – Set Paper Thickness to the recommendation on the next page.

Platen Gap – Set to Wide if you experience head strikes – black marks or scrapes on your print.

Contact Red River Paper

support@redriverpaper.com

888-248-8774

MEDIA SETTING RECOMMENDATIONS

Paper	Media Setting	Special
GLOSSY / SEMIGLOSS		
66lb. Polar Pearl Metallic	Premium Photo Paper Glossy	
68lb. UltraPro Gloss 2.0	Premium Photo Paper Glossy	
66lb. Arctic Polar Gloss	Premium Photo Paper Glossy	
60lb. & 42lb. Pecos River Gloss	Photo Paper Glossy	
96lb. Pecos River Gloss Magna	Photo Paper Glossy	Paper Thickness 4
86lb. Pecos River Gloss Duo	Photo Paper Glossy	Paper Thickness 4
45lb. Zeppelin SemiGloss MK	Ultra Premium Presentation Paper Matte	Matte Black Ink
45lb. Zeppelin SemiGloss PK	Premium Photo Paper Semi-Gloss	Photo Black Ink
San Gabriel Baryta SemiGloss 2.0	Ultra Premium Photo Paper Luster	Paper Thickness 4
Palo Duro SoftGloss Rag	Premium Photo Paper Semi-Gloss	Paper Thickness 4
SATIN / LUSTER		
68lb. UltraPro Satin 4.0 / 3.0	Ultra Premium Photo Paper Luster	
66lb. Palo Duro Satin	Ultra Premium Photo Paper Luster	
66lb. Arctic Polar Satin	Ultra Premium Photo Paper Luster	
Arctic Polar Luster – All Weights	Ultra Premium Photo Paper Luster	
RR Luster Duo	Ultra Premium Photo Paper Luster	
MATTE / FINE ART		
Premium Matte Papers – All Weights	Ultra Premium Presentation Paper Matte	
60lb. Polar Matte / Double Sided	Ultra Premium Presentation Paper Matte	
88lb. Polar Matte Magna	Ultra Premium Presentation Paper Matte	Paper Thickness 4
60lb. River Linen 2.0	Ultra Premium Presentation Paper Matte	
60lb. Paper Canvas	Ultra Premium Presentation Paper Matte	
64lb. Aurora Art Natural	Ultra Premium Presentation Paper Matte	Paper Thickness 4 Color Density -5%
64lb. Aurora Art White	Ultra Premium Presentation Paper Matte	Paper Thickness 4 Color Density -5%
Blanco Matte Canvas	Enhanced Matte Paper or Ultra Premium Presentation Paper Matte	Platen Gap Wide Paper Thickness 5 Color Density -5%
Palo Duro Etching	Velvet Fine Art	Paper Thickness 5

Handling Guides

Check our website to see if your paper has a Handling Guide. Guides contain important information and helpful tips. www.redriverpaper.com/guides

Epson 3880 Insider Notes

Special Controls

Mac - From the Print menu locate the Advanced Media Control.

You will find Paper Thickness, Platen Gap, and Color Density controls therein.


The screenshot shows the 'Advanced Media Control' dialog box. At the top, there is a range selector 'From: 1 to: 1'. Below this is the title 'Advanced Media Control' with a dropdown arrow. The settings are as follows:

- Color Density:** A slider ranging from -50 to +50 (%). The value is set to 0.
- Drying Time per Print Head Pass:** A slider ranging from 0 to +50 (0.1sec). The value is set to 0.
- Paper Feed Adjustment:** A slider ranging from -10 to +10 (0.01%). The value is set to 0.
- Paper Thickness:** A numeric input field showing '3' with a unit of '(0.1mm)'. A red arrow points to this field.
- Platen Gap:** A dropdown menu set to 'Standard'.

At the bottom right is a 'Default' button. At the very bottom are buttons for 'PDF', 'Hide Details', 'Cancel', and 'Print'.

Windows - From the Main tab locate and click on the Paper Config button.

You will find Paper Thickness, Platen Gap, and Color Density controls in the Paper Configuration dialog.



Further Help

Go to <http://www.redrivercatalog.com/infocenter/> for more help with driver settings and more.