



Printer Color Profile Instructions

Color profiles are data files that contain a description of how a particular paper, ink, and printer create all colors, shades, and densities. Using a profile will result in more accurate and consistent output.

Printer: Epson SureColor P600

Setting Recommendations

Mode: Off No Color Adjustment

Print Quality: Quality Options / Level 4 (1440x720) – High Speed optional

Support


How to install profiles

www.redriverpaper.com/installprofiles

How to use profiles

www.redriverpaper.com/useprofiles

Some Hints

 The name of the paper you are using will not be listed in the media setting drop down menu in the printer driver. That menu only has the names of manufacturer papers.

Do not use the printer driver's "Preview before printing feature". It can interrupt the color management process.

Turn on your printer's thick paper setting when using heavy weight papers.

Epson Printers – Set Paper Thickness to recommended setting on the next page.

Platen Gap – Set to Wide if you experience head strikes – black marks or scrapes on your print.

Contact Red River Paper

support@redriverpaper.com

888-248-8774

MEDIA SETTING RECOMMENDATIONS

Paper	Media Setting	Special
68lb. UltraPro Gloss 2.0	Premium Photo Paper Glossy	
60lb. & 42lb. Pecos River Gloss	Photo Paper Glossy	
96lb. Pecos River Gloss	Photo Paper Glossy	Paper Thickness 4
86lb. Pecos River Gloss Duo	Photo Paper Glossy	Paper Thickness 4
UltraPro Luster 300	Ultra Premium Photo Paper Luster	
68lb. UltraPro Satin 4.0	Ultra Premium Photo Paper Luster	
66lb. Palo Duro Satin	Ultra Premium Photo Paper Luster	
66lb. Arctic Polar Satin	Ultra Premium Photo Paper Luster	
Arctic Polar Luster – All Weights	Ultra Premium Photo Paper Luster	
Polar Metallic Papers	Premium Photo Paper Glossy	
Premium Matte – All Weights	Ultra Premium Presentation Paper Matte	
60lb. Polar Matte / Double Sided	Ultra Premium Presentation Paper Matte	
88lb. Polar Matte	Ultra Premium Presentation Paper Matte	Paper Thickness 4
60lb. River Linen 2.0	Ultra Premium Presentation Paper Matte	
60lb. Paper Canvas	Ultra Premium Presentation Paper Matte	
Aurora Art Natural	Ultra Premium Presentation Paper Matte	Paper Thickness 4 Color Density -5%
Aurora Art White	Ultra Premium Presentation Paper Matte	Paper Thickness 4 Color Density -5%
Big Bend Baryta 310	Premium Semigloss Photo Paper	Paper Thickness 4
Blanco Satin Canvas	Exhibition Canvas Satin	Paper Thickness 5 Platen Gap Wide
Blanco Matte Canvas	Ultra Premium Presentation Paper Matte	Paper Thickness 5 Platen Gap Wide
Palo Duro SoftGloss Rag	Legacy Platine	Paper Thickness 4
Palo Duro Etching 315	Velvet Fine Art	Paper Thickness 5
Palo Duro Smooth Rag 310	Ultra Smooth Fine Art Paper	Paper Thickness 5
Palo Duro Baryta Fiber 300 *** See note below***	Premium Photo Paper Semigloss	Paper Thickness 4 Platen Gap Wide Color Density -8%

Handling Guides

Check our website to see if your paper has a Handling Guide. Guides contain important information and helpful tips. www.redriverpaper.com/guides

Palo Duro Baryta Fiber Notes

REDUCE COLOR DENSITY

Epson printers tend to put down a great deal of ink with the media setting required for this paper. As a result, with large sheets with full coverage you may see slight ripples.

You can avoid this issue by reducing Color Density. We recommend starting at minus 8 and go now lower than minus 15. See below for how to adjust this setting.

Set the Platen Gap and Paper Thickness per our recommendation. It is important to avoid head strikes and streaking in the print.

Remember!

Just like darkroom paper, Palo Duro Baryta is a sensitive material and should be handled with care.

ADVANCED MEDIA CONTROLS

Epson includes important controls for Paper Thickness, Platen Gap, and Color Density in this menu.

Mac - From the Print menu locate the Advanced Media Control.

From: 1 to: 1

Advanced Media Control

Color Density:

0 -50 +50 (%)

Drying Time per Print Head Pass:

0 0 +50 (0.1sec)

Paper Feed Adjustment:

0 -10 +10 (0.01%)

Paper Thickness:

3 (0.1mm)

Platen Gap:

Standard

Default

PDF


Hide Details

Cancel

Print

Windows - From the Main tab locate and click on the Paper Config (1) button.

You will find Paper Thickness (3), Platen Gap (2), and Color Density (4) controls in the Paper Configuration dialog.



Further Help

Go to <http://www.redrivercatalog.com/infocenter/> for more help with driver settings and more.