



## Printer Color Profile Instructions

Color profiles are data files that contain a description of how a particular paper, ink, and printer create all colors, shades, and densities. Using a profile will result in more accurate and consistent output.

**Printer:** Epson Stylus Pro 4880 / 7880 / 9880

### Setting Recommendations

**Mode:** Off No Color Adjustment

**Print Quality:** Quality Options / Level 4 (1440x720) – High Speed optional

### Support

How to install profiles

[www.redriverpaper.com/installprofiles](http://www.redriverpaper.com/installprofiles)

How to use profiles

[www.redriverpaper.com/useprofiles](http://www.redriverpaper.com/useprofiles)

### Some Hints



The name of the paper you are using will not be listed in the media setting drop down menu in the printer driver. That menu only has the names of manufacturer papers.

Do not use the printer driver's "Preview before printing feature". It can interrupt the color management process.

Turn on your printer's thick paper setting when using heavy weight papers.

- Epson Printers – Set Paper Thickness using recommendation on next page
- Platen Gap – Set to Wide if you experience head strikes – black marks or scrapes on your print.

### Contact Red River Paper

support@redriverpaper.com

888-248-8774

## MEDIA SETTING RECOMMENDATIONS

Paper	Media Setting	Special
<b>UltraPro Gloss 2.0</b>	Premium Glossy Photo Paper (250)	
<b>Pecos River Gloss</b>	Premium Glossy Photo Paper (250)	
<b>UltraPro Satin</b>	Premium Luster Photo Paper (260)	
<b>Palo Duro Satin</b>	Premium Luster Photo Paper (260)	
<b>Arctic Polar Satin</b>	Premium Luster Photo Paper (260)	
<b>Arctic Polar Luster</b>	Premium Luster Photo Paper (260)	
<b>Polar Metallic Papers</b>	Premium Glossy Photo Paper (250)	
<b>Premium Matte Papers</b>	Ultra Premium Presentation Paper Matte	
<b>River Linen 2.0</b>	Ultra Premium Presentation Paper Matte	
<b>Paper Canvas</b>	Ultra Premium Presentation Paper Matte	
<b>Aurora Art Natural</b>	Ultra Premium Presentation Paper Matte	<a href="#">Paper Thickness 4</a>
<b>Aurora Art White</b>	Ultra Premium Presentation Paper Matte	<a href="#">Paper Thickness 4</a>
<b>San Gabriel Baryta SemiGloss 2.0</b>	Premium Luster Photo Paper (260)	<a href="#">Paper Thickness 4</a>
<b>Blanco Satin Canvas</b>	Exhibition Satin Canvas	<a href="#">Paper Thickness 5</a>
<b>Blanco Matte Canvas</b>	Ultra Premium Presentation Paper Matte	<a href="#">Paper Thickness 5</a>
<b>Palo Duro SoftGloss Rag</b>	Premium Luster Photo Paper (260)	<a href="#">Paper Thickness 4</a>
<b>Palo Duro Etching 315</b>	Velvet Fine Art	<a href="#">Paper Thickness 5</a>
<b>Palo Duro Smooth Rag 310</b>	Ultra Smooth Fine Art	<a href="#">Paper Thickness 5</a>
<b>Palo Duro Baryta Fiber 300</b> *** See note below ***	Premium Semigloss Photo Paper	<a href="#">Platen Gap Wide</a> <a href="#">Paper Thickness 4</a> Color Density -8%

## Handling Guides

Check our website to see if your paper has a Handling Guide. Guides contain important information and helpful tips. [www.redriverpaper.com/guides](http://www.redriverpaper.com/guides)

## NOTES ON PALO DURO BARYTA FIBER 300

### REDUCE COLOR DENSITY

Epson printers tend to put down a great deal of ink with the media setting required for this paper. As a result, with large sheets with full coverage you may see slight ripples.

You can avoid this issue by reducing Color Density. We recommend starting at minus 8 and go now lower than minus 15. See below for how to adjust this setting.

Set the Platen Gap and Paper Thickness per our recommendation. It is important to avoid head strikes and streaking in the print.


#### Remember!

Just like darkroom paper, Palo Duro Baryta is a sensitive material and should be handled with care.

### ADVANCED MEDIA CONTROLS

**Mac** - From the Print menu locate the Advanced Media Control.

You will find Paper Thickness, Platen Gap, and Color Density controls therein.



**Windows** - From the Main tab locate and click on the Paper Config button.

You will find Paper Thickness, Platen Gap, and Color Density controls in the Paper Configuration dialog.

