



Printer Color Profile Instructions

Color profiles are data files that contain a description of how a particular paper, ink, and printer create all colors, shades, and densities. Using a profile will result in more accurate and consistent output.

Printer: Epson Stylus Pro 4880 / 7880 / 9880

Setting Recommendations

Mode: Off No Color Adjustment

Print Quality: Quality Options / Level 4 (1440x720) – High Speed optional

Support

How to install profiles

www.redriverpaper.com/installprofiles

How to use profiles

www.redriverpaper.com/useprofiles

Some Hints



The name of the paper you are using will not be listed in the media setting drop down menu in the printer driver. That menu only has the names of manufacturer papers.

Do not use the printer driver's "Preview before printing feature". It can interrupt the color management process.

Turn on your printer's thick paper setting when using heavy weight papers.

- Epson Printers – Set Paper Thickness to 4
- Platen Gap – Set to Wide if you experience head strikes – black marks or scrapes on your print.

Contact Red River Paper

support@redriverpaper.com

888-248-8774

MEDIA SETTING RECOMMENDATIONS

Paper	Media Setting	Special
UltraPro Gloss 2.0	Premium Glossy Photo Paper (250)	
Arctic Polar Gloss	Premium Glossy Photo Paper (250)	
Pecos River Gloss	Premium Glossy Photo Paper (250)	
UltraPro Satin	Premium Luster Photo Paper (260)	
Palo Duro Satin	Premium Luster Photo Paper (260)	
Arctic Polar Satin	Premium Luster Photo Paper (260)	
Arctic Polar Luster	Premium Luster Photo Paper (260)	
Polar Pearl Metallic	Premium Glossy Photo Paper (250)	
Aurora Art Natural & White	Ultra Premium Presentation Paper Matte	Paper Thickness 4
Premium Matte Papers	Ultra Premium Presentation Paper Matte	
River Linen 2.0	Ultra Premium Presentation Paper Matte	
Paper Canvas	Ultra Premium Presentation Paper Matte	
GreenPix Photo Matte	Ultra Premium Presentation Paper Matte	
San Gabriel SemiGloss Fiber	Premium Semigloss Photo Paper (250)	Paper Thickness 4
Blanco Matte Canvas	Ultra Premium Presentation Paper Matte	Paper Thickness 5
Palo Duro SoftGloss Rag	Premium Semigloss Photo Paper (250)	Paper Thickness 4

Handling Guides


Check our website to see if your paper has a Handling Guide. Guides contain important information and helpful tips. www.redriverpaper.com/guides

Insider Notes

Special Controls

Mac - From the Print menu locate the Advanced Media Control.

You will find Paper Thickness, Platen Gap, and Color Density controls therein.



Windows - From the Main tab locate and click on the Paper Config button.

You will find Paper Thickness, Platen Gap, and Color Density controls in the Paper Configuration dialog.

