



Printer Color Profile Instructions – Epson Expression XP850

Color profiles are data files that contain a description of how a particular paper, ink, and printer create all colors, shades, and densities. Using a profile will result in more accurate and consistent output.

Color Management Driver Setting: ICM > Off (No Color Adjustment)

Print Quality: Photo

Paper	Media Setting
UltraPro Gloss	Ultra Premium Photo Paper Glossy
Arctic Polar Gloss	Ultra Premium Photo Paper Glossy
Pecos River Gloss	Premium Photo Paper Glossy
UltraPro Satin	Ultra Premium Photo Paper Luster
Arctic Polar Satin	Ultra Premium Photo Paper Luster
Arctic Polar Luster	Ultra Premium Photo Paper Luster
Polar Pearl Metallic	Ultra Premium Photo Paper Glossy
Zeppelin SemiGloss	Premium Photo Paper Semi-Gloss
Premium Matte Papers	Premium Presentation Paper Matte
River Linen 2.0	Premium Presentation Paper Matte
Paper Canvas	Premium Presentation Paper Matte

How to Install Profiles – www.redriverpaper.com/installprofiles

How to Use Printer Profiles – www.redriverpaper.com/useprofiles

The name of the paper you are using will not be listed in the media setting drop down menu in the printer driver. That menu only has the names of manufacturer papers.

Do not use the printer driver's "Preview before printing feature". It can interrupt the color management process.

Contact Red River Paper

customerservice@redriverpaper.com

888-248-8774