



Printer Color Profile Instructions / Setting Recommendations

Color profiles are data files that contain a description of how a particular paper, ink, and printer create all colors, shades, and densities. Using a profile will result in more accurate and consistent output.

Canon

Media Type: Photo Paper Plus Semi-gloss

Color / Intensity: Manual

Manual Color Adjustment > Matching Tab > Color Correction > None

Print Quality: Highest setting

Epson

Media Type: Ultra Premium Photo Paper Luster

Color Mode: Off / No Color Adjustment

Print Quality: Photo or Superfine 1440dpi.

Some Hints

*Turn on your printer's thick media setting for best results. Help on the topic is here:

<http://tinyurl.com/3frqsck>

Epson - For users that have the Paper Config menu:

Platen Gap - Wide or Wider

Paper Thickness - 4

*The name of the paper you are using will not be listed in the media setting drop down menu in the printer driver. That menu only has the names of manufacturer papers.

*Do not use the printer driver's "Preview before printing feature". It can interrupt the color management process.

More Profile Information

Go to www.redriverpaper.com/profiles for help, information, and more.