



Printer Color Profile Instructions

Color profiles are data files that contain a description of how a particular paper, ink, and printer create all colors, shades, and densities. Using a profile will result in more accurate and consistent output.

Printer: Epson P600

Setting Recommendations

Mode: Off No Color Adjustment

Print Quality: Quality Options / Level 4 – High Speed optional

Paper	Media Setting	Special
68lb. UltraPro Gloss 2.0	Premium Photo Paper Glossy	
66lb. Arctic Polar Gloss	Premium Photo Paper Glossy	
60lb. Pecos River Gloss	Photo Paper Glossy	
96lb. Pecos River Gloss	Photo Paper Glossy	
45lb. Zeppelin SemiGloss	Ultra Premium Presentation Paper Matte	Platen Gap Wide
68lb. UltraPro Satin 4.0	Ultra Premium Photo Paper Luster	
66lb. Palo Duro Satin	Ultra Premium Photo Paper Luster	
66lb. Arctic Polar Satin	Ultra Premium Photo Paper Luster	
Arctic Polar Luster – All Weights	Ultra Premium Photo Paper Luster	
66lb. Polar Pearl Metallic	Premium Photo Paper Glossy	
Premium Matte Papers	Ultra Premium Presentation Paper Matte	
60lb. Polar Matte / Double Sided	Ultra Premium Presentation Paper Matte	
88lb. Polar Matte Magna	Ultra Premium Presentation Paper Matte	Platen Gap Wide
72lb. GreenPix	Ultra Premium Presentation Paper Matte	
60lb. Paper Canvas	Ultra Premium Presentation Paper Matte	
64lb. Aurora Art Natural	Ultra Premium Presentation Paper Matte	
64lb. Aurora Art White	Ultra Premium Presentation Paper Matte	
San Gabriel SemiGloss Fiber	Premium Photo Paper Semigloss	Platen Gap Wide Paper Thickness 6
Blanco Matte Canvas	Ultra Premium Presentation Paper Matte	Platen Gap Wide Paper Thickness 6
96lb. Pecos River Gloss Magna	Photo Paper Glossy	Platen Gap Wide Paper Thickness 6

Support

How to install profiles

www.redriverpaper.com/installprofiles

How to use profiles

www.redriverpaper.com/useprofiles

Some Hints

Turn on your printer's thick paper setting when using heavy weight papers.

Go to the Paper Configuration menu and set the Platen Gap to Wide. For very thick media, set Paper Thickness to 6.

The name of the paper you are using will not be listed in the media setting drop down menu in the printer driver. That menu only has the names of manufacturer papers.

Do not use the printer driver's "Preview before printing feature". It can interrupt the color management process.

Contact Red River Paper

support@redriverpaper.com

888-248-8774