



Printer Color Profile Instructions

Color profiles are data files that contain a description of how a particular paper, ink, and printer create all colors, shades, and densities. Using a profile will result in more accurate and consistent output.

Printer: Epson Stylus Pro P10000 and P20000

Setting Recommendations

Mode: Off No Color Adjustment

Recommended Quality Settings – for best quality and economy

Print Quality: Quality Options / Level 4 (SuperFine 1440x720)

High Speed: Off

Edge Smoothing : Off

Finest Detail: On

Support

How to install profiles

www.redriverpaper.com/installprofiles

How to use profiles

www.redriverpaper.com/useprofiles

Some Hints



The name of the paper you are using will not be listed in the media setting drop down menu in the printer driver. That menu only has the names of manufacturer papers.

Do not use the printer driver's "Preview before printing feature". It can interrupt the color management process.

Turn on your printer's thick paper setting when using heavy weight papers.

- Epson Printers – Set Paper Thickness to the recommended setting on the next page.
- Platen Gap – Set to Wide if you experience head strikes – black marks or scrapes on your print.

Contact Red River Paper

support@redriverpaper.com

888-248-8774

MEDIA SETTING RECOMMENDATIONS

Paper	Media Setting	Special
UltraPro Gloss 2.0	Premium Glossy Photo Paper (250)	
UltraPro Luster 300	Premium Luster Photo Paper (260)	
UltraPro Satin	Premium Luster Photo Paper (260)	
Arctic Polar Satin	Premium Luster Photo Paper (260)	
Arctic Polar Luster	Premium Luster Photo Paper (260)	
Polar Metallic Papers	Premium Glossy Photo Paper (250)	
Polar Matte Papers	Ultra Premium Presentation Paper Matte	
Aurora Art White	Hot Press Bright	Paper Thickness 4
Aurora Art Natural	Hot Press Natural	Paper Thickness 4
Palo Duro Matte Canvas	Canvas Matte	Paper Thickness 5
Palo Duro Satin Canvas	Exhibition Canvas Satin	Paper Thickness 5
Palo Duro Gloss Canvas	Exhibition Canvas Gloss	Paper Thickness 5
Palo Duro Metallic Canvas	Exhibition Canvas Gloss	Paper Thickness 5

Handling Guides


Check our website to see if your paper has a Handling Guide. Guides contain important information and helpful tips. www.redriverpaper.com/guides

Insider Notes

Special Controls

Mac - From the Print menu locate the Advanced Media Control.

You will find Paper Thickness, Platen Gap, and Color Density controls therein.



Windows - From the Main tab locate and click on the Paper Config button.

You will find Paper Thickness, Platen Gap, and Color Density controls in the Paper Configuration dialog.

