



Printer Color Profile Instructions – Epson 4000 7600 9600

Color profiles are data files that contain a description of how a particular paper, ink, and printer create all colors, shades, and densities. Using a profile will result in more accurate and consistent output.

Color Management Driver Setting: ICM > Off (No Color Adjustment)

Recommended Print Quality: Level 4, High Speed Off

Paper	Media Setting
UltraPro Gloss 2.0	Premium Glossy Photo Paper
Arctic Polar Gloss 2.0	Premium Glossy Photo Paper
Pecos River Gloss	Premium Glossy Photo Paper
UltraPro Satin 3.0	Premium Luster Photo Paper
Arctic Polar Satin	Premium Photo Paper Luster
Arctic Polar Luster	Premium Photo Paper Luster
Polar Pearl Metallic	Premium Glossy Photo Paper
Aurora Art Natural & White	Archival Matte Paper
Premium Matte Papers	Enhanced Matte Paper
River Linen	Enhanced Matte Paper
Paper Canvas	Enhanced Matte Paper
GreenPix Photo Matte	Enhanced Matte Paper
San Gabriel SemiGloss Fiber	Premium Semigloss Photo Paper (250)
Blanco Matte Canvas	Enhanced Matte Paper

How to Install Profiles – www.redriverpaper.com/installprofiles

How to Use Printer Profiles – www.redriverpaper.com/useprofiles

The name of the paper you are using will not be listed in the media setting drop down menu in the printer driver. That menu only has the names of manufacturer papers.

Do not use the printer driver's "Preview before printing feature". It can interrupt the color management process.