



Printer Color Profile Instructions

Color profiles are data files that contain a description of how a particular paper, ink, and printer create all colors, shades, and densities. Using a profile will result in more accurate and consistent output.

Printer: Epson SureColor P5000

Setting Recommendations

Mode: Off No Color Adjustment

Print Quality: Quality Options / SuperFine Level 4 (720x1440) – High Speed optional

Support

How to install profiles

www.redriverpaper.com/installprofiles

How to use profiles

www.redriverpaper.com/useprofiles

Some Hints



The name of the paper you are using will not be listed in the media setting drop down menu in the printer driver. That menu only has the names of manufacturer papers.

Do not use the printer driver's "Preview before printing feature". It can interrupt the color management process.

Turn on your printer's thick paper setting when using heavy weight papers.

- Epson Printers – Set Paper Thickness to recommendation on the next page.
- Platen Gap – Set to Wide if you experience head strikes – black marks or scrapes on your print.

PK = Photo Black Ink

MK = Matte Black Ink

Contact Red River Paper

support@redriverpaper.com

888-248-8774

Handling Guides

Check our website to see if your paper has a Handling Guide. Guides contain important information and helpful tips.

www.redriverpaper.com/guides

Paper	Media Setting	Special
68lb. UltraPro Gloss 2.0	Premium Glossy Photo Paper (250)	
60lb. & 42lb. Pecos River Gloss	Premium Glossy Photo Paper (250)	
96lb. Pecos River Gloss 86lb. Pecos River Gloss Duo	Premium Glossy Photo Paper (250)	Paper Thickness 4
UltraPro Luster 300	Premium Luster Photo Paper (260)	
68lb. UltraPro Satin 4.0	Premium Luster Photo Paper (260)	
66lb. Palo Duro Satin	Premium Luster Photo Paper (260)	
66lb. Arctic Polar Satin	Premium Luster Photo Paper (260)	
Arctic Polar Luster – All Weights	Premium Luster Photo Paper (260)	
Polar Metallic Papers	Premium Glossy Photo Paper (250)	
Premium Matte Papers – All Weights	Ultra Premium Presentation Paper Matte	
60lb. Polar Matte / Double Sided	Ultra Premium Presentation Paper Matte	
88lb. Polar Matte	Ultra Premium Presentation Paper Matte	Paper Thickness 4
60lb. River Linen 2.0	Ultra Premium Presentation Paper Matte	
60lb. Paper Canvas	Ultra Premium Presentation Paper Matte	
Aurora Art Natural	Hot Press Natural	Paper Thickness 4 Color Density -5%
Aurora Art White	Ultra Premium Presentation Paper Matte	Paper Thickness 4 Color Density -5%
San Gabriel Baryta SemiGloss 2.0	Premium Luster Photo Paper (260)	Paper Thickness 4
Blanco Matte Canvas	Exhibition Canvas Matte	Platen Gap Wide Paper Thickness 5
Blanco Satin Canvas	Exhibition Canvas Satin	Platen Gap Wide Paper Thickness 5
Palo Duro SoftGloss Rag	Legacy Platine	Paper Thickness 4
Palo Duro Etching 315	Cold Press Natural	Paper Thickness 5
Palo Duro Smooth 310	Ultra Smooth Fine Art Paper	Paper Thickness 5

Palo Duro Baryta Fiber 300 *** See note below ***	Premium Semigloss Photo Paper	Platen Gap Wide Paper Thickness 4
---	-------------------------------	--

NOTES ON PALO DURO BARYTA FIBER 300

REDUCE COLOR DENSITY

Epson printers tend to put down a great deal of ink with the media setting required for this paper. As a result, with large sheets with full coverage you may see slight ripples.

You can avoid this issue by reducing Color Density. We recommend starting at minus 8 and go now lower than minus 15. See below for how to adjust this setting.

Set the Platen Gap and Paper Thickness per our recommendation. It is important to avoid head strikes and streaking in the print.

Remember!


Just like darkroom paper, Palo Duro Baryta is a sensitive material and should be handled with care.

ADVANCED MEDIA CONTROLS

Epson includes important controls for Paper Thickness, Platen Gap, and Color Density in this menu.

Mac - From the Print menu locate the Advanced Media Control.

You will find Paper Thickness, Platen Gap, and Color Density controls therein.



Windows - From the Main tab locate and click on the Paper Config button.

You will find Paper Thickness, Platen Gap, and Color Density controls in the Paper Configuration dialog.

